

Model 36600-Series

ELECTRIC BILGE PUMPS

FEATURES

- · Self-Priming
- Diaphragm Design Allows Dry Running
- Quiet Operation
- Built-in Hydraulic Pulsation Dampener
- Permanently Lubricated Ball Bearings on Shaft and Connecting Rod
- Large Vibration Absorbing Pads
- Corrosion Resistant Materials Throughout for Sea Water Service
- Meets USCG Regulation 183.410 and ISO 8846 MARINE for Ignition Protection

SPECIFICATIONS

Open Flow: 8.0 GPM
Vert. Dry Suction Lift: 10 feet (3 m)
Ports: 3/4" Slip-on Hose

Weight: 11 lb

APPLICATION

Jabsco diaphragm bilge pumps are self-priming, so they can be mounted above and outside of harsh bilge environments. Because they are mounted remotely, the intake hose can be routed to the lowest point of the bilge regardless of space limitations. They are supplied with an in-line strainer to prevent damaging debris from entering pump. The reliable diaphragm design is not damaged by dry running.

INSTALLATION

MOUNTING

Mount upright in a dry location (above highest bilge water level) on a solid surface. Adjust belt tension for 1/4" play between pulleys.

PLUMBING

For intake and discharge use 3/4" ID non-collapsible hose. Keep intake and discharge lines free of kinks and restrictions. Use the 3/4" bilge in-line stainer (Model 36200-0000) in the intake line from the bilge to protect pump from debris. Use a 3/4" thru-hull fitting for discharge.



STANDARD MODELS

| 12 Vdc | 11.0 |
|---------|--------|
| 24 Vdc | 5.5 |
| 115 Vac | 1.0 |
| | 24 Vdc |

WIRING FOR DC VOLTAGE MODELS:

Wire pump in a circuit independent of all other electrical fixtures. Use stranded copper wire. Install fuse/breaker in positive circuit. See table for recommended wire and fuse size. See diagram for wiring connections. Use a 10 amp-rated switch 44960-0000. After installation, it is recommended that voltage be checked at the motor terminals with motor operating under full load and all other appliances in the circuit operating. Voltage should not be less than 90% of rated motor voltage.

Jabsco Pumps 36600-0031


www.PumpAgents.com - Click here for Pricing/Ordering for Pumps and Parts

ELECTRICAL SPECIFICATIONS

| Model | | Wire Size for Length of Run | Fuse/ | | |
|------------|---------|-----------------------------|------------|-----------|--|
| Number | Voltage | 1-25 feet | 25-50 feet | Breaker* | |
| 36600-0000 | 12 Vdc | 12 AWG | 10 AWG | 15 amp | |
| 36600-0010 | 24 Vdc | 14 AWG | 14 AWG | 8 amp | |
| 36600-0031 | 115 Vac | 16 AWG | 16 AWG | 1-1/2 amp | |

^{*} Customer supplied, not included with pump.

WIRING DIAGRAM FOR AUTOMATIC OPERATION



WIRING FOR AC VOLTAGE MODEL:

Use 16 gauge stranded copper wire for lengths up to 100 feet from power source. Connect the grounded, unswitched conductor (white) to the white motor lead. Connect the ungrounded switched conductor (black) to the black motor lead. This conductor should include, at the power source, a 1.5 amp 125 volt fuse. The green motor lead must be connected to the AC circuit ground.

MAINTENANCE

WINTER STORAGE:

When possible it is preferred that the complete pump be removed and stored in a warm dry place. If this is not possible the pump must be completely drained, hoses removed and pump run until all water is expelled.

TROUBLESHOOTING

| Problems | Causes |
|---------------------------|---|
| Loss of suction to pump. | -Air leak in suction lineBilge pickup not submergedIntake hose kinked or pluggedFouled intake or discharge valveRuptured diaphragm. |
| Rough or noisy operation. | -Intake or discharge hose kinked or plugged. -Pump not mounted firmly. -Loosened eccentric screw. -Ruptured or collapsed pulsation dampener. |

SERVICE

DIAPHRAGM AND CONNECTING ROD REPLACEMENT

- 1. Turn off power to pump. Remove four tie down bolts.
- 2. Lift jack shaft and the attached diaphragm assembly from pump base.
- 3. Remove two diaphragm retainer screws and the diaphragm retainer.
- 4. Remove lock nut. Remove connecting rod and diaphragm from jack shaft, then unscrew bolt to separate diaphragm and plates.
- Check diaphragm for cuts and cracks. Check rod assembly bearing for excessive wear. Replace if badly worn.
- Loosely reassemble diaphragm, diaphragm plates, washer and diaphragm bolt onto connecting rod. Firmly secure connecting rod to jack shaft with the lock nut. Secure diaphragm to motor mount with the diaphragm retainer and two screws.
- 7. Tighten connecting rod bolt.

VALVE REPLACEMENT

- 1. Turn off power to pump. Remove four tie down bolts.
- Expose valves by lifting jack shaft and attached diaphragm assembly from pump base. Remove and clean or replace valves.
- 3. Install valves, making sure rubber flapper is UP on intake and DOWN on discharge.
- Replace motor-mount-diaphragm assembly and fasten evenly to base with the four tie down bolts.

PULSATION DAMPENERS REPLACEMENT

- 1. Disconnect power leads from pump and remove from mount.
- 2. Remove nine bottom cap screws and three bottom plate screws. Remove bottom cap and plate. Pull out and replace pulsation dampeners.
- 3. Replace bottom cap, plate and screws. Tighten evenly to ensure air and water seals.
- 4. Reinstall pump and reconnect power leads.

Jabsco Pumps 36600-0031

www.PumpAgents.com - Click here for Pricing/Ordering for Pumps and Parts

EXPLODED VIEW **Indicates items included in Hardware Kit (Key 21).

MARINE SWITCH PANELS



44960-0000 **LIGHTED SWITCH** W/BOOT SPDT (DC APPLICATIONS ONLY) (AC OR DC APPLICATIONS)



44960-0001 **UNLIGHTED SPDT**

AUTOMATIC BILGE PUMP SWITCH




MODEL 30295-2000 FLOAT SWITCH (DC APPLICATIONS ONLY)

PARTS LIST 36600-Series

| Key | Description | Qty. | Part Number |
|-----|----------------------------|-------|---------------------------|
| 1 | Motor Kit 12 Volt DC | 1 | 30200-0000 |
| | Motor Kit 24 Volt DC | | 30200-0010 |
| | Motor Kit 115 Volt AC | | 30200-0031 |
| 2 | Motor Mount | 1 | 34628-0000 |
| 3 | Small Pulley | 1 | 37169-0000 |
| 4 | Large Pulley | 1 | 37171-0001 |
| 5 | Belt | 1 | 30022-0000* |
| 6 | Jack Shaft Assembly | 1 | 35691-0001 -See Note 1 |
| 7 | Connecting Rod Kit | 1 | 37173-0001 -See Note 1 |
| 8 | Diaphragm Plate | 2 | 35212-0000 |
| 9 | Diaphragm | 1 | 30016-0000* |
| 10 | Retainer | 1 | 35173-0000 |
| 11 | Valve Set (Inlet & Outlet) | 1 Set | 30003-0000*† |
| 12 | Base Assembly † | 1 | 35630-1100 |
| 13 | Ports (Inlet & Outlet) | 1 | 30003-0000*† |
| 14 | Small Pulsation Dampene | er 1 | 37177-0000*† |
| 15 | Pulsation Dampener | 1 | 37178-0000*† |
| 16 | Small Bottom Plate | 1 | 35628-0000† |
| 17 | Bottom Plate | 1 | 35623-0000† |
| 20 | Vibration Pad Kit | | 37180-0000† |
| 21 | Hardware Kit | 1 Set | 37165-0000 |
| | Service Kit* | 1 Set | 30124-0000 |

Indicates Parts Contained in Service Kit.

NOTE 1 – Jack shaft assembly kit, with part number ending in -0001 includes new style connecting rod (37173-0001) with a 5/16" diameter hole and two (2) locknuts. Previous model pumps use a connecting rod (37173-0000) with a 1/4" diameter hole and a bolt.



FLOAT SWITCH COVER



MODEL 30294-2000 (DC APPLICATIONS ONLY)

[†] Indicates Parts supplied with Base Assembly.

Jabsco Pumps 36600-0031

www.PumpAgents.com - Click here for Pricing/Ordering for Pumps and Parts

ONE YEAR LIMITED WARRANTY

A. LIMITED WARRANTY:

JABSCO warrants that at the time of shipment, the products manufactured by JABSCO and sold hereunder shall be in conformity with applicable written specifications and descriptions referred to or set forth herein, free from defects in material and workmanship, merchantable, and suitable for a particular purpose, provided such is implied by State law under the circumstances of this sale.

B. WARRANTY ADJUSTMENT:

- JABSCO agrees to repair or furnish a replacement for, but not to remove or install, any product or component thereof which, within one (1) year from date of purchase, shall upon test and examination by JABSCO prove defective within the above warranty. Receipt verifying purchase date is required to obtain adjustment.
- Buyer shall notify JABSCO of any defect within this warranty no later than ninety (90) days after the defect is discovered.
- 3. No product will be accepted for return or replacement without the prior written authorization of JAB-SCO. Upon such authorization, and in accordance with instructions from JABSCO, the product will be returned to JABSCO, shipping charges prepaid by Buyer. Products returned to JABSCO will be addressed as follows:

JABSCO Cape Ann Industrial Park Gloucester, MA 01930

Or to such alternate locations as may be designated on the product, its container, or this sheet.

Repair or replacement made under this warranty will be shipped prepaid to Buyer.

C. EXCLUSIONS FROM WARRANTY AND LIMITATION OF LIABILITY:

 The foregoing warranty is limited solely as set forth herein and applies only for the period designated above.

- 2. JABSCO SHALL NOT BE LIABLE FOR ANY LOSS, DAMAGE, SPECIAL OR CONSEQUENTIAL DAMAGE OF ANY KIND, WHETHER BASED UPON WARRANTY, CONTRACT, NEGLIGENCE, OR STRICT LIABILITY ARISING IN CONNECTION WITH THE SALE, USE, OR REPAIR OF THE PRODUCT.
- 3. THE MAXIMUM LIABILITY OF JABSCO IN CON-NECTION WITH THIS WARRANTY SHALL NOT IN ANY CASE EXCEED THE CONTRACT PRICE FOR THE PRODUCT CLAIMED TO BE DEFECTIVE OR UNSUITABLE.
- This warranty does not extend to any product manufactured by JABSCO which has been subjected to misuse, neglect, accident, improper installation, or use in violation of instructions furnished by JABSCO.
- 5. This warranty does not extend to or apply to any unit which has been repaired or altered at any place other than JABSCO's factory, or by persons not expressly approved by JABSCO, nor to any unit the serial number, model number, or identification of which has been removed, defaced or changed.
- 6. Components manufactured by any supplier other than JABSCO shall bear only that warranty made by the manufacturer of that product.
- 7. This warranty applies to products defined as "consumer products" by the Consumer Product Warranties Act as from time to time amended.

D. CONSUMER RIGHTS:

This warranty gives you specific legal rights, and you may have other rights which vary from state to state. Some states do not allow exclusion or limitation of damages.

STANDARD WARRANTY: If the products manufactured and sold hereunder are not Consumer Products, the warranty extended to Buyer shall be as set forth in subparagraphs (A), (B), and (C), EXCEPT THAT ALL EXPRESS OR IMPLIED WARRANTIES OR MERCHANTABILITY OR SUITABILITY FOR ANY PARTICULAR PURPOSE ARE EXCLUDED.

INSPECTION UPON REQUEST.

Form: 43000-0107

THE PRODUCTS DESCRIBED HEREIN ARE SUBJECT TO THE JABSCO ONE YEAR LIMITED

WARRANTY, WHICH IS AVAILABLE FOR YOUR

Jabsco



U.S.A. Jabsco Cape Ann Industrial Park Gloucester, MA 01930 Tel: 978.281.0440 Fax: 978.283.2619 UNITED KINGDOM Jabsco Bingley Road, Hoddesdon Hertfordshire EN11 OBU Tel: +44 (0) 1992 450145 Fax: +44 (0) 1992 467132 CANADA Fluid Products Canada 55 Royal Road Guelph, Ontario N1H 1T1 Tel: 519 821.1900 Fax: 519 821.2569

All Rights Reserved

JAPAN NHK Jabsco Company Ltd. 3-21-10, Shin-Yokohama Kohoku-Ku, Yokohama, 222 Tel: 045.475.8906 Fax: 045.475.8908

GERMANY Jabsco GmbH Oststrasse 28 22840 Norderstedt Tel: +49-40-53 53 73 -0 Fax: +49-40-53 53 73 -11

Rev 05/2004